



NOTES:

1. PLEASE CALL 937-428-4782 FOR INSPECTION ONE DAY PRIOR TO PLACEMENT OF ASPHALT.
2. ELEVATION AT RIGHT OF WAY IS EQUAL TO $\frac{1}{2}$ " PER 1' ABOVE TOP OF CURB. A TYPICAL DRIVEWAY AT 10' R/W LINE WILL BE 5" ABOVE THE TOP OF STANDARD HEIGHT CURB.
3. TACK COAT BACK OF CURB PER ODOT 401.14 BEFORE ASPHALT IS PLACED.
4. IF STREET HAS CONCRETE WALK, DRIVE APRON MUST BE CONCRETE.
5. NOTE IF REPLACING CURB: CONTACT INSPECTOR PRIOR TO SAWING CURB. DEPRESSED CURB SHALL BE $1\frac{1}{2}$ " ABOVE THE FLOW LINE OF CURB. 12" HORIZONTAL TRANSITION FOR DEPRESSED CURB.



CITY OF
CENTERVILLE, OH
PUBLIC WORKS DEPARTMENT
7970 SOUTH SUBURBAN ROAD
CENTERVILLE, OHIO 45458
PHONE (937) 428-4782
FAX (937) 433-0286

C441
COMMERCIAL
ASPHALT
DRIVE APRON

Approval:

James Brinegar
City Engineer

Date: Sept. 2020
Revision: Jan. 2021
Scale: None
Sheet: 1 of 1